

## ENGINEERING CHANGE NOTICE

Date: 03.06.25		ECN #: 538			
Project No.: D206-667	Created By: <i>[Signature]</i>	Checked By: <i>[Signature]</i>			
Project Name: 206 CROSS TUBES	Approved By: <i>[Signature]</i> (proj. manager)	Approved By: <i>[Signature]</i> (management if req'd)	N/A		
Description of Change: RELEASE D3193 REV. A DSF 9263 REV. A					
Notification/Acceptance	Affected	Authorization			
QA	✓	P401			
Production	✓				
Planning	✓				
Marketing	✓				
Engineering Actions	Yes	No	Responsible	To happen by:	Complete
Update Blue File 667	✓		KJ	03.07.01	03.07.02 <i>[Signature]</i>
Update Pink File 667	✓		KJ	03.07.01	03.07.02 <i>[Signature]</i>
Update D-Part Master Binder	✓		KJ	03.07.01	03.07.02 <i>[Signature]</i>
Update Grey Project Binder	✓		DS	03.07.01	03.07.04 <i>[Signature]</i>
Update DEO Binder	✓		DS	03.07.01	03.07.04 <i>[Signature]</i>
Update Master Document List		✓			
Update Drawing Approval Record	✓		DS	03.08.01	04.11.26 <i>[Signature]</i>
Update Change Record Form	✓		DS	03.07.01	03.07.04 <i>[Signature]</i>
Move Electronic File	✓		DS	03.07.01	03.07.04 <i>[Signature]</i>
Notify TCA of Change	✓		DS	03.08.01	04.11.26 <i>[Signature]</i>
Notify FAA of Change		✓			
Update QSI 021		✓			
Update QSI 036		✓			
Scan Documents	✓		KJ	03.07.01	03.07.02 <i>[Signature]</i>
Update MIS Database	✓		KJ	03.07.01	03.07.02 <i>[Signature]</i>
Update Access Database	✓		KJ	03.07.01	03.07.02 <i>[Signature]</i>
Verification ARC	✓		DS/KJ	03.07.01	03.07.03 <i>[Signature]</i>
Notes:					
<ul style="list-style-type: none"> <li>- SPACER BLOCKS COMING IN FROM EAGLE TO GET US STARTED - INSPECT AND IDENTIFY AS D3193-041 → QTY (10)</li> <li>- CREATE UP FOR D206-667-011 → KIT TO INCLUDE DSF 9263 REV. A</li> <li>- CREATE PPP FOR D206-667-011 → D206-667-011 AT CHG 001</li> <li>- CREATE BOM FOR P206-667-011 done 03.07.02 <i>[Signature]</i></li> <li>- PROGRAMMING &amp; MACHINING OF D3193-041 TO COME LATER.</li> <li>- CREATE W/O TO CREATE 4 X D206-667-011 SPACER BLOCK KITS.</li> </ul>					